

The seat drop value described in the compatibility table is primarily a value relative to the original-equipment seat.

It is measured by mounting a Recaro Reclining seat.

— **explanatory note** — Differences may arise due to the position of the thickness and shape of the bottom of the seat, and seat settling due to aging of the original-equipment seat.

Note: If the original-equipment seat incorporates a height adjustment function, this value is relative to the lowest position.

Note: As a general rule, driver's seat data (passenger seats have different values depending on the presence or absence of height adjustment function)

## LEXUS

Model Name	Model Code	Seat Drop	Type	Right Part No.	Left Part No.	Side SRS	Remarks
GS	UZS190,GRS191	-35mm	B4	DLS1010B04R	DLS1010B04L	NPC001	2WD Offset toward door side is 9 mm. The slide sensor needs to be relocated. Specialty garage recommended for installation.
GS	GRS196	-35mm	B4	DLS1020B04R	DLS1020B04L	NPC001	4WD Offset toward door side is 9 mm. The slide sensor needs to be relocated. Specialty garage recommended for installation.
GS	GRL10,GRL11,GRL12 GWL10,ARL10,AWL10	-20mm	B6	DLS1051B06R	DLS1051B06L	NPC002	4WD/GRL15,16 to be determined. Offset toward door side is 10 mm. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
GS-F	URL10	-20mm	B6	DLS1052B06R	DLS1052B06L	NPC002	Offset toward door side is 10 mm. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
HS	ANF10	-10mm	B36	DLS1030B36R	DLS1030B36L	NPC001	If the driver's side electric seat contains a position memory, it must be removed.
IS	GSE20,21	-20mm	B4	DLS1040B04R	DLS1040B04L	NPC001	4WD/GSE25 to be determined. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
IS-F	USE20	-20mm	B4	DLS1041B04R	DLS1041B04L	NPC001	The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
IS	USE30 GSE30,31	-20mm	B6	DLS1050B06R	DLS1050B06L	NPC002	Offset toward door side is 10 mm. 4WD/GSE35 to be determined. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
LS	USF40	-20mm	B16	DLS1060B16R	DLS1060B16L	NPC001	4WD/F45,F46 to be determined. The slide sensor needs to be relocated. Specialty garage recommended for installation.

LS500	VXFA50,55	-15mm	B6	DLS1140B06R	DLS1140B06L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500	VXFA50,55	-15mm	LB9	DLS1140B09R	DLS1140B09L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500h	GVF50,55	-15mm	B6	DLS1150B06R	DLS1150B06L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500h	GVF50,55	-15mm	LB9	DLS1150B09R	DLS1150B09L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
RC	AVC,ASC,GSC10	-20mm	B1	DLS1070B01R	DLS1070B01L	NPC002	It is necessary to rearrange the passenger CPU and the position memory. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
RC-F	USC10	-20mm	B1	DLS1071B01R	DLS1071B01L	NPC002	It is necessary to rearrange the passenger CPU and the position memory. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
RX200,450	L20W,L25W	±0mm	B36	DLS1080B36R	DLS1080B36L	NPC002	Cars with a submarine prevention function require a canceller.(NPC001×1pcs) The slide sensor needs to be relocated.
RX450h,350,RX270	L10,L15,L16	-20mm	B36	DLS1090B36R	DLS1090B36L	NPC001	The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Interferes with shoulder width exceeding 630 mm.
SC430	UZZ40	-10mm	B6	DLS1130B06R	DLS1130B06L	NPC001	Common to Aristo (JZS160). Down amount is data of Aristo (JZS160).
UX	MZAA10,MZAA15 MZAH10,MZAH15	-10mm	B6	DLS1120B06R	DLS1120B06L	NPC002	Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Other electronic devices unconfirmed.
UX	MZAA10,MZAA15 MZAH10,MZAH15	-10mm	LB9	DLS1120B09R	DLS1120B09L	NPC002	Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Other electronic devices unconfirmed.