

— explanatory note —

The seat drop value described in the compatibility table is primarily a value relative to the original-equipment seat. It is measured by mounting a Recaro or Bride full bucket seat at the lowest position possible without the seat bottom interfering with the seat rail or vehicle floor. Differences may arise due to the position of the seat to be mounted (the position of the bolt holes), the thickness and shape of the bottom of the seat, and seat settling due to aging of the original-equipment seat.

Note: If the original-equipment seat incorporates a height adjustment function, this value is relative to the lowest position.

Note: As a general rule, driver's seat data (passenger seats have different values depending on the presence or absence of height adjustment function)

## LEXUS

Model Name	Model Code	Seat Drop	Type	Right Part No.	Left Part No.	Side SRS	Remarks
GS	UZS190,GRS191	-35mm	S4	DLS1010S04R	DLS1010S04L	NPC001	2WD Offset toward door side is 9 mm. The slide sensor needs to be relocated. Specialty garage recommended for installation.
GS	GRS196	-35mm	S4	DLS1020S04R	DLS1020S04L	NPC001	4WD Offset toward door side is 9 mm. The slide sensor needs to be relocated. Specialty garage recommended for installation.
GS	GRL10,GRL11,GRL12 GWL10,ARL10,AWL10	-20mm	S6	DLS1051S06R	DLS1051S06L	NPC002	4WD/GRL15,16 to be determined. Offset toward door side is 10 mm. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
GS-F	URL10	-20mm	S6	DLS1052S06R	DLS1052S06L	NPC002	Offset toward door side is 10 mm. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
HS	ANF10	-10mm	S36	DLS1030S36R	DLS1030S36L	NPC001	If the driver's side electric seat contains a position memory, it must be removed.
IS	GSE20,21	-20mm	S4	DLS1040S04R	DLS1040S04L	NPC001	4WD/GSE25 to be determined. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
IS-F	USE20	-20mm	S4	DLS1041S04R	DLS1041S04L	NPC001	The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
IS	USE30 GSE30,31	-20mm	S6	DLS1050S06R	DLS1050S06L	NPC002	Offset toward door side is 10 mm. 4WD/GSE35 to be determined. The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
LS	USF40	-20mm	S16	DLS1060S16R	DLS1060S16L	NPC001	4WD/F45,F46 to be determined. The slide sensor needs to be relocated. Specialty garage recommended for installation.

LS500	VXFA50,55	-15mm	S6	DLS1140S06R	DLS1140S06L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500	VXFA50,55	-15mm	LS9	DLS1140S09R	DLS1140S09L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500h	GVF50,55	-15mm	S6	DLS1150S06R	DLS1150S06L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
LS500h	GVF50,55	-15mm	LS9	DLS1150S09R	DLS1150S09L	NPC002	Offset toward door side is 8 mm. It is necessary to relocate the memory unit and surface pressure sensor. Recommended to work at a maintenance shop.
RC	AVC,ASC,GSC10	-20mm	S1	DLS1070S01R	DLS1070S01L	NPC002	The slide sensor needs to be relocated. It is necessary to rearrange the passenger CPU and the position memory. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
RC-F	USC10	-20mm	S1	DLS1071S01R	DLS1071S01L	NPC002	The slide sensor needs to be relocated. It is necessary to rearrange the passenger CPU and the position memory. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp.
RX200,450	L20W,L25W	±0mm	S36	DLS108S36R	DLS108S36L	NPC002	Cars with a submarine prevention function require a canceller.(NPC001×1pcs) The slide sensor needs to be relocated.
RX450h,350,RX270	L10,L15,L16	-20mm	S36	DLS109S36R	DLS109S36L	NPC001	The slide sensor needs to be relocated. Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Interferes with shoulder width exceeding 630 mm.
SC430	UZZ40	-10mm	S6	DLS1130S06R	DLS1130S06L	NPC001	Common to Aristo (JZS160). Down amount is data of Aristo (JZS160).
UX	MZAA10,MZAA15 MZAH10,MZAH15	-10mm	S6	DLS1120S06R	DLS1120S06L	NPC002	Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Other electronic devices unconfirmed.
UX	MZAA10,MZAA15 MZAH10,MZAH15	-10mm	LS9	DLS1120S09R	DLS1120S09L	NPC002	Passenger seat is equipped with a surface pressure sensor for the seat belt warning lamp. Other electronic devices unconfirmed.